FORD Mondeo III 2000-

AUTOMOTIVE

FSK6410 / FSK6411 Ford Mondeo III rear subframe bushes

SPECIAL INSTRUCTIONS & FITTING TIPS

Thoroughly clean the mounting holes in the subframe prior to installation of the new bushes.

Apply **Loctite270** © to the outer circumference of the bush and ensure that it is correctly aligned before pressing in.

IMPORTANT NOTE

The vehicle may be moved but must not be driven for 24hrs to allow the **Loctite 270** © to fully cure.

First Line recommend that the subframe bushes are replaced as a full set.



FSK6410 Front 'V Shaped' head



FSK6411 Rear straight head

J&S Automotive Distributors

Unit 17, Park West Road, Park West, Dublin 12, Ireland t: 01-629 7999 If: 01-629 5664

e: sales@jsautomotive.ie | w: www.jsautomotive.ie