

# SNR WHEEL BEARING KITS



With Kits for around fifty vehicle brands, the SNR Wheel Automotive Aftermarket range covers more than 95% of the European car parc.

## WHEN SHOULD A WHEEL BEARING BE CHANGED?

- After an accidental impact
- When the surrounding parts are damaged
- When the bearing itself is damaged (improper installation, installation in bad conditions, etc.)
- When it has been fitted for a very many miles/kilometres (a bearing is a wearing part)


## WHAT DOES A FAULTY BEARING MEAN?

- Deterioration of road holding (steering, braking)
- Noisy rotation of the wheel
- Increased wear of the surrounding parts (hub, suspension)

AN SNR WHEEL BEARING KIT = SNR QUALITY = PASSENGER SAFETY  
AT COMPETITIVE PRICES

## COMPONENTS OF AN SNR KIT

Our kits can have different parts, depending on which vehicle will be repaired :



**J&S AUTOMOTIVE DISTRIBUTORS STOCKS OVER  
330 WHEEL BEARING KITS  
(ALSO IN STOCK NTN-SNR BRAKE DISC KITS)**

**CALL 01-629 7999 TO ORDER YOUR  
NTN-SNR WHEEL BEARING KITS NOW!**



J&S Automotive Distributors  
Unit 17, Park West Road, Park West, Dublin 12  
t 01-629 7999 f 01-620 5664